

# **JET**

**JBS-12**

**WOODWORKING BANDSAW**

**100001021M**

**~230V, 50Hz**

## **PARTS LIST**

**JPW (TOOL) AG**

Tämperlistrasse 5

CH-8117 Fällanden

Switzerland

Phone +41 44 806 47 48

Fax +41 44 806 47 58

[www.jettools.com](http://www.jettools.com)



M-100001021M

2015-04-01



## Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
1	JBS12-001	Circlip ring 17x1	Sicherungsring 17x1
2	JBS12-002	Ball bearing 6203	Rillenkugellager 6203
3	JBS12-003	Upper band saw wheel assembly	Baugruppe oberes Bandsägenrad
4	JBS12-004	Upper bearing shaft	Obere Lagerwelle
5	JBS12-005	Wheel carrier bracket	Radträgerbügel
6	JBS12-006	Spring washer M16	Federscheibe M16
7	JBS12-007	Hexagonal nut -M16x1.5	Sechskantmutter -M16x1.5
8	JBS12-008	Special Screw for tension	Spezialschraube für Spannung
9	JBS12-009	Starlock ring 10mm	Starlock Sicherungsring 10mm
10	JBS12-010	Cylindrical pin 11x100	Zylindrischer Stift 11x100
11	JBS12-011	Tension bracket	Spannungsbügel
12	JBS12-012	Slotted inset	Geschlitzter Einsatz
13	JBS12-013	Saddle washer	Schlittenscheibe
14	JBS12-014	Lock housing	Verriegelungsgehäuse
15	JBS12-015	Nylon washer	Nylonscheibe
16	JBS12-016	Hexagonal nut M22x1.5	Sechskantmutter M22x1.5
17	JBS12-017	Tongue lock	Zungenverriegelung
18	JBS12-018	Serrated lock washer 6mm	Gezahnte Verriegelungsscheibe 6mm
19	JBS12-019	Hexagonal bolt -M6x10	Sechskantschraube -M6x10
20	JBS12-020	Leaf spring	Blattfeder
21	JBS12-021	Door-upper assembly	Tür - obere Baueinheit
22	JBS12-022	Circlip ring 40	Sicherungsring 40
23	JBS12-023	Lamello plug	Lamello Stecker
24	JBS12-024	Blade tension knob	Blattspannungsknopf
25	JBS12-025	Blade tensioner	Blattspanner
26	JBS12-026	Flat washer 8 mm	Flache Scheibe 8 mm
27	JBS12-027	Hexagonal head screw M8x16	Sechskantkopfschraube M8x16
28	JBS12-028	Blade tracking knob	Blattnachführungsknopf
29	JBS12-029	Wing nut M8	Flügelmutter M8
30	JBS12-030	Door Switch assembly	Tür Endschalter komplett
30-1	JBS12-030-1	Pan head tapping screw 3.5x20	Flachkopfbandschraube 3.5x20
30-2	JBS12-030-2	Flat washer 4mm	Scheibe 4mm
30-3	JBS12-030-3	Door Switch Box A	Schaltergehäuse Box A
30-4	JBS12-030-4	Door Switch	Endschalter
30-5	JBS12-030-5	Door Switch Box B	Schaltergehäuse Box B
31	JBS12-031	Tension bracket frame	Spannungsbügelrahmen
32	JBS12-032	Flange nut M8 galvanised	Flanschmutter M8 galvanisiert
33	JBS12-033	Frame for Bandsaw	Bandsäge-Rahmen

## Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
34	JBS12-034	Spacer bush	Distanzhülse
35	JBS12-035	Pan head tapping screw 4.8x16	Flachkopfbandschraube 4.8x16
36	JBS12-036	Serrated lock washer 5 mm	Gezahnte Schraubensicherung 5 mm
37	JBS12-037	Plate	Platte
38	JBS12-038	Carriage bolt M8x20	Flachrundschraube mit Nase M8x20
39	JBS12-039	Bolt guide	Schraubenführung
40	JBS12-040	Hexagonal bolt -M6x20	Sechskantschraube - M6x20
41	JBS12-041	Clinch Bolt	Nietbolzen
42	JBS12-042	Guide bracket	Führungsbügel
43	JBS12-043	Serrated lock washer 6 mm	Gezahnte Schraubensicherung 6 mm
44	JBS12-044	Hexagonal nut M6	Sechskantmutter M6
45	JBS12-045	Saw blade guard assembly	Sägeblattschutz Baueinheit
46	JBS12-046	Slide	Schlitten
47	JBS12-047	Screw M4x12	Schraube M4x12
48	JBS12-048	Guide adjust screw M6x16	Führungsjustierschraube
49	JBS12-049	Grooved ball bearing 608	Rillenkugellager 608
50	JBS12-050	Flat washer 6 mm	Flache Scheibe 6 mm
51	JBS12-051	3-roller guide assembly	3-Rollenführung Baueinheit
52	JBS12-052	Hexagonal nut M6	Sechskantmutter M6
53	JBS12-053	Bolt guide, small	Schraubenführung, klein
54	JBS12-054	Screw socket set M6x12	Schraubenaufnahmesatz M6x12
55	JBS12-055	Guide shaft	Führungswelle
56	JBS12-056	Upper guide mount	Obere Führungsaufnahme
57	JBS12-057	Flat washer 8 mm	Flache Scheibe 8 mm
58	JBS12-058	Hexagonal nut M8, nylonstop	Sicherungsmutter M8
59	JBS12-059	Hexagonal bolt -M6x20	Sechskantschraube M6x20
60	JBS12-060	Bearing mount cylinder w/cap	Lageraufnahmezylinder mit Abdeckung
61	JBS12-061	Hexagonal nut M8	Sechskantmutter M8
62	JBS12-062	Clamp	Klemme
63	JBS12-063	Pan head Screw M5x10	Linsenkopfschraube M5x10
64	JBS12-064	Bearing mount cylinder	Lageraufnahmezylinder
65	JBS12-065	Flange nut M8	Flanschmutter M8
66	JBS12-066	Washer	Scheibe
67	JBS12-067	Wire jacket	Kabeldurchführung
68	JBS12-068	Saw blade 2240x13x0,5mm-4TPI	Sägeblatt 2240x13x0,5mm-4Z"
69	JBS12-069	Door-lower assembly	Tür - untere Baueinheit
70	JBS12-070	Hexagonal nut M4, nylonstop	Sicherungsmutter M4

## Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
71	JBS12-071	Flat washer 4 mm	Flache Scheibe 4 mm
72	JBS12-072	Saw blade guard	Sägeschutz unten
73	JBS12-073	Hexagonal screw -M4x12	Sechskantschraube - M4x12
74	JBS12-074	On/Off magnetic switch 1~230V	Ein/Aus Magnetschalter 1~230V
75	JBS12-075	Carriage bolt M8x100	Flachrundschraube mit Nase M8x100
76	JBS12-076	Brush	Bürste
77	JBS12-077	Spacer bush 8x50	Distanzbuchse 8x50
78	JBS12-078	Lower band saw wheel assembly	Baugruppe unteres Bandsägenrad
79	JBS12-079	Grooved ball bearing 6001	Genutetes Kugellager 6001
80	JBS12-080	Tension wheel	Spannrad
81	JBS12-081	Circlip ring 12x1	Sicherungsring 12x1
82	JBS12-082	Circlip ring 28	Sicherungsring 28
83	JBS12-083	Sliding shaft	Schiebewelle
84	JBS12-084	Set Screw M6x12	Gewindestift M6x12
85	JBS12-085	Hexagonal nut -M20x1.5	Sechskantmutter - M20x1.5
86	JBS12-086	Lower bearing shaft	Untere Lagerwelle
87	JBS12-087	Poly-v-belt	Rippenkeilriemen
88	JBS12-088	Motor belt pulley	Motorriemenscheibe
90	JBS12-090	Hexagonal screw -M6x16	Sechskantschraube -M6x16
91	JBS12-091	Spring washer 6 mm	Federscheibe 6 mm
92	JBS12-092	Set collar 10 mm	Stellring 10 mm
93	JBS12-093	Set ScrewM5x8	Gewindestift M5x8
94	JBS12-094	Disk washer 20x10.2x0.8	Scheibe 20x10.2x0.8
95	JBS12-095	Crank	Kurbel
96	JBS12-096	Suction connector Rd 100	Saugstutzen Dm 100
97	JBS12-097	Washer 6mm	Scheibe 6mm
98	JBS12-098	Hexagonal nut M6	Sechskantmutter M6
99	JBS12-099	Hexagonal screw -M6x20	Sechskantschraube M6x20
100	JBS12-100	Hexagonal flat nut-M6	Sechskantflachmutter - M6
101	JBS12-101	Crank handle	Kurbelhandgriff
102	JBS12-102	Cap screw M6x55	Kopfschraube M6x55
103	JBS12-103	Motor P2=0.55kW, 1~230V, 50Hz	Motor P2=0.55kW, 1~230V, 50Hz
103-1	JBS12-103-1	Motor Terminal Box	Motor Klemmenkasten
103-2	JBS12-103-2	Capacitor	Kondensator
103-3	JBS12-103-3	Motor Fan	Lüfterrad
103-4	JBS12-103-4	Motor Fan Cover	Lüfterrad-deckel
104	JBS12-104	Pin guide set	Sifführungs-satz


## Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
105	JBS12-105	Lower guide support	Untere Führungsauflage
106	JBS12-106	Pointer	Zeiger
107	JBS12-107	Machine Screw ST3.5x9	Blechschraube ST3.5x9
108	JBS12-108	Tilt Degree Scale	Schwenkskala
109	JBS12-109	Rip fence carrier	Parallelanschlag-Träger
110	JBS12-110	Miter Gauge Assembly	Gehrungsanschlag komplett
110-1	JBS12-110-1	Pan Head Machine Screw	Blechschraube
110-2	JBS12-110-2	Fence Plate A	Endkappe A
110-3	JBS12-110-3	Guide Base	Gehrungsanschlag-Träger
110-4	JBS12-110-4	Clinch Bolt	Nietbolzen
110-5	JBS12-110-5	Ruler	Skala
110-6	JBS12-110-6	Handle	Griff
110-7	JBS12-110-7	Pointer	Zeiger
110-8	JBS12-110-8	Pointer Base	Zeiger Träger
110-9	JBS12-110-9	Pin	Stift
110-10	JBS12-110-10	Screw M3x16	Schraube M3x16
110-11	JBS12-110-11	Bolt	Stehbolzen
110-12	JBS12-110-12	Washer 6	Scheibe 6
110-13	JBS12-110-13	Support Strip	T-Profil
110-14	JBS12-110-14	Shaft Screw M6	Gewindestift M6
110-15	JBS12-110-15	Lock Knob	Klemmgriff
110-16	JBS12-110-16	Carriage bolt M6x30	Flachrundschraube M6x30
110-17	JBS12-110-17	Guide Fence	Gehrungsanschlag-Aluprofil
110-18	JBS12-110-18	Fence Plate B	Endkappe B
112	JBS12-112	Knurled thumb screw M6x25 galvanised	Hohe Rändelschraube M6x25 galvanisiert
113	JBS12-113	Knurled nut M6	Rändelmutter M6
114	JBS12-114	Washer flat 6 mm	Scheibe flach 6 mm
115	JBS12-115	Carriage bolt M6x40	Flachrundschraube mit Nase M6x40
116	JBS12-116	Fence extrusion	Parallelanschlag-Aluprofil
117	JBS12-117	Bolt guide	Schraubenführung
118	JBS12-118	Carriage bolt M8x50	Flachrundschraube mit Nase M8x50
119	JBS12-119	Table	Tisch
120	JBS12-120	Table insert	Tischeinlage
123	JBS12-123	Scale-metric	Skala - metrisch
124	JBS12-124	Rip fence carrier extrusion	Anschlagführung
125	JBS12-125	Hexagonal nut M6	Sechskantmutter M6
126	JBS12-126	Power Cord 230V for JBS-12	

## Parts List For JBS-12 Woodworking Bandsaw

Pos.	Art. Nr.	Description	Beschreibung
130	JBS12-130	Wing nut M8	Flügelmutter M8
134	JBS12-134	Glide piece	Gleitstück
135	JBS12-135	Table trunion upper	Obere Tischwippe
136	JBS12-136	Serrated lock washer 8 mm	Gezahnte Schraubensicherung 8 mm
137	JBS12-137	Hexagonal screw M8x20	Sechskantschraube M8x20
140	JBS12-140	Table trunion lower	Untere Tischwippe
200	JBS12-200	Band saw tyre 315x2.5x20	Rollenauflage 315x2.5x20

### Bandsaw Stand



Pos.	Art. Nr.	Description	Beschreibung
301	JBS12-301	Hex. Nut M 6	Sechskantmutter M6
302	JBS12-302	Washer 6	Scheibe 6
303	JBS12-303	Hexagonal screw –M6x40	Sechskantschraube M6x40
304	JBS12-304	Hex. Nut M8	Sechskantmutter M8
305	JBS12-305	Hexagonal screw –M8x16	Sechskantschraube M8x16
306	JBS12-306	Support Plate A	Querstrebe A
307	JBS12-307	Support Plate B	Querstrebe B
308	JBS12-308	Stand Leg	Standfubein
309	JBS12-309	Rubber Foot	Gummiteller
310	JBS12-310	Support Plate C	Querstrebe C
311	JBS12-311	Support Plate D	Querstrebe D

# Wiring Diagram for JBS-12 Woodworking Band Saw

100001021M

1~230V, 50Hz

	colour of strands	Litzenfarben	cordons
BK	black	schwarz	noir
BU	blue	blau	bleu
BN	brown	braun	brun
GNYE	green-yellow	grün-gelb	vert-jaune

	meaning of symbol	Bedeutung	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
LS	limit switch	Endschalter	micro

